


ITEMS SUPPLIED IN VALVE KIT - OPTIONAL (WITH AIR ELIMINATOR)




| COMPONENT NAME | QTY. |
|--|------|
| A) Non-Return isolation & Pressure reduction valve. | 1 |
| B) 4 way tee. | 1 |
| C) Elbow. | 3 |
| D) Tempering valve. | 1 |
| E) Straight adaptor 1/2 x 1/2 Inch. | 2 |
| F) Cold water expansion control valve. | 1 |
| G) Air eliminator Tee. | 1 |
| H) Air eliminator. | 1 |
| I) Coupling. | 1 |
| J) Flow meter. | 1 |
| K) High temp. check valve. (500mm above pump) | 1 |
| L) Compression tee. | 1 |
| M) Pump and control box.* | 1 |
| N) Temp. sensor cable.* | 2 |
| O) Cap plug. | 1 |
| P) Pressure, temp. relief valve. (Included with tank)* | 1 |
| Q) Tank* | 1 |
| R) Collector* | 1 |
| S) Hot water tee | 1 |
| T) Manifold adaptor* (Comes with manifold) | 2 |
| U) Straight adaptor 1/2 x 3/4 Inch. | 1 |



*These components are included in a standard SolarArk System.

ITEMS SUPPLIED IN VALVE KIT - OPTIONAL (WITHOUT AIR ELIMINATOR)




| COMPONENT NAME | QTY. |
|--|------|
| A) Non-Return isolation & Pressure reduction valve. | 1 |
| B) 4 way tee. | 1 |
| C) Elbow. | 3 |
| D) Tempering valve. | 1 |
| E) Straight adaptor 1/2 x 1/2 Inch. | 2 |
| F) Cold water expansion control valve. | 1 |
| G) Coupling. | 1 |
| H) Flow meter. | 1 |
| I) High temp. check valve. (500mm above pump) | 1 |
| J) Compression tee. | 1 |
| K) Pump and control box.* | 1 |
| L) Temp. sensor cable.* | 2 |
| M) Pressure, temp. relief valve. (Included with tank)* | 1 |
| N) Tank* | 1 |
| O) Collector* | 1 |
| P) Hot water tee | 1 |
| Q) Manifold adaptor* (Comes with manifold) | 2 |
| R) Straight adaptor 1/2 x 3/4 Inch. | 1 |

*These components are included in a standard SolarArk System.

ITEMS SUPPLIED IN VALVE KIT - OPTIONAL (WITH AIR ELIMINATOR & GAS BOOSTER)

SolarArk


BETTER BY DESIGN



| COMPONENT NAME | QTY. |
|--|------|
| A) Non-Return isolation & Pressure reduction valve. | 1 |
| B) 4 way tee. | 1 |
| C) Elbow. | 3 |
| D) Tempering valve. | 1 |
| E) Straight adaptor 1/2 x 1/2 Inch. | 2 |
| F) Cold water expansion control valve. | 1 |
| G) Gas boost heater.* | 1 |
| H) Coupling. | 1 |
| I) Flow meter. | 1 |
| J) High temp. check valve. (500mm above pump) | 1 |
| K) Compression tee. | 1 |
| L) Pump and control box.* | 1 |
| M) Temp. sensor cable.* | 1 |
| N) Pressure, temp, relief valve. (Included with tank)* | 1 |
| O) Tank* | 1 |
| P) Collector* | 1 |
| Q) Hot water tee | 1 |
| R) Manifold adaptor* (Comes with manifold) | 2 |
| S) Straight adaptor 1/2 x 3/4 Inch. | 1 |
| T) Air eliminator Tee. | 1 |
| U) Air eliminator. | 1 |
| V) Cap plug. | 1 |

*These components are included in a standard SolarArk System.

ITEMS SUPPLIED IN VALVE KIT - OPTIONAL (WITH GAS BOOSTER & NO AIR ELIMINATOR)



| COMPONENT NAME | QTY. |
|--|------|
| A) Non-Return isolation & Pressure reduction valve. | 1 |
| B) 4 way tee. | 1 |
| C) Elbow. | 3 |
| D) Tempering valve. | 1 |
| E) Straight adaptor 1/2 x 1/2 Inch. | 2 |
| F) Cold water expansion control valve. | 1 |
| G) Gas boost heater | 1 |
| H) Coupling. | 1 |
| I) Flow meter. | 1 |
| J) High temp. check valve. (500mm above pump) | 1 |
| K) Compression tee. | 1 |
| L) Pump and control box.* | 1 |
| M) Temp. sensor cable.* | 1 |
| N) Pressure, temp, relief valve. (Included with tank)* | 1 |
| O) Tank* | 1 |
| P) Collector* | 1 |
| Q) Hot water tee | 1 |
| R) Manifold adaptor* (Comes with manifold) | 2 |
| S) Straight adaptor 1/2 x 3/4 Inch. | 1 |

*These components are included in a standard SolarArk System.